RODUCT DATA

## PRODUCT DESCRIPTION

Stonchem 502 is a high performance, epoxy hybrid lining system applied at a nominal thickness of 1 mm. The mortarcoat, topcoat sequencing provides a light-duty chemical barrier for areas with occasional foot traffic. The Stonchem 502 system has excellent resistance to caustics and moderate concentrations of acids.

# **USES, APPLICATIONS**

- · Secondary containment areas
- Concrete pads and pedestals
- Process piping and equipment
- Storage tanks
- Neutralization pits
- Splash/spill areas

## **PRODUCT ADVANTAGES**

- Excellent chemical resistance to caustics and moderate concentrations of acids
- · Mineral composite filled for increased impermeability
- Factory proportioned units for easy application

## **CHEMICAL RESISTANCE**

Stonchem 502 is formulated to resist a variety of chemical solutions. Refer to the Stonchem 500 Series Chemical Resistance Guide which lists reagent concentration and temperature recommendations for each product.

#### **PACKAGING**

Stonchem 502 is packaged in units for easy handling. Each unit consists of:

#### Mortarcoat

0.5 carton of Stonchem 500 Series mortercoat

A carton contains:

- 4 foil bags of amine
- 4 polybags of resin
- 2 bags of Mortarcoat aggregate

## Topcoat

1 carton of Stonchem 500 Series Topcoat

A carton contains:

- 4 foil bags of amine
- 4 polybags of resin

### **COVERAGE**

Each unit of Stonchem 502 will cover approximately 16.72 m<sup>2</sup> at a thickness of 1 mm.

**Note**: Coverage rates shown are theoretical. Actual coverage rates may vary. Make necessary allowances for the condition of the surface to be coated, working conditions, waste, spillage, experience level and skill of the installers, etc.

# STORAGE CONDITIONS

Store all components between 10 to 24°C in a dry area. Keep out of direct sun light. When stored in the unopened containers at the proper temperatures, the shelf life is 3 years.

## **SUBSTRATE**

Stonchem 502, with appropriate primer, is suitable for application over concrete and the following uncoated newly applied Stonhard mortars and grouts: GS, HT, UR, UT, TG6, TG8, CR5 and PM5. For questions regarding other possible substrates or an appropriate primer, contact your local Stonhard representative or Technical Service.

## SUBSTRATE PREPARATION

Proper preparation is critical to ensure an adequate bond and system performance. The substrate must be dry and properly prepared utilizing mechanical methods. Questions regarding substrate preparation should be directed to your local Stonhard representative or Technical Service.

# **APPLICATION GUIDELINES**

For optimal working conditions, substrate temperature must be between 15 to 27°C. Cold areas must be heated until the slab temperature is above 13°C to ensure the material achieves a proper cure. A cold substrate will make the material stiff and difficult to apply. Warm areas or areas in direct sunlight must be shaded or arrangements made to work during evenings or at night. A warm substrate (15 to 27°C) will aid in the material's workability; however, a hot substrate (27 to 37°C) or a substrate directly in

#### PHYSICAL CHARACTERISTICS

Tensile Strength 30.34 N/mm<sup>2</sup>

(ASTM D-638)

Flexural Strength 82.74 N/mm<sup>2</sup>

(ASTM C-580)

Flexural Modulus of Elasticity 5.0 x 0.72 N/mm<sup>2</sup>

(ASTM C-580)

Hardness 85-90

(ASTM D-2240, Shore D)

**Abrasion Resistance** 0.07 gm max. weight loss

(ASTM D-4060, CS-17) Thermal Coefficient

of Linear Expansion 2 x 10-5 in./in.°C

(ASTM C-531)

Colour Gray
Cure Rate 4 to 6 hours tack-free
(@21°C) 24 hours chemical service

VOC

(ASTM D-2369, Method E)

Stonchem 500 Topcoat - 55 g/l Stonchem 500 Series Liquids – 45g/l

**Note**: The above physical properties were measured in accordance with the referenced standards. Samples of the actual floor system, including binder and filler, were used as test specimens.

the sun will shorten the material's working time and can cause other phenomenon such as pin holing and bubbling. Substrate temperature must be greater than 3°C above dew point during application and curing period. Application and curing times are dependent upon ambient and surface conditions. Consult Stonhard's Technical Service Department if conditions are not within recommended guidelines.

#### **APPLYING**

### **Priming**

Vacuum the surface before priming and make sure the substrate is dry. The use of Stonchem Epoxy Primer is necessary in all applications of Stonchem 502. This ensures maximum product performance. (See the Stonchem Epoxy Primer product data sheet for details.)

**Note:** Stonchem Epoxy Primer must be tack-free prior to application of the mortarcoat.

#### Mortarcoat

After the primer has been applied and allowed to fully cure, pre-mix the amine and resin in a 20 litre mixing bucket with a heavy-duty, slow-speed drill (400 to 600 rpm) with a Jiffy Mixer attachment for 1 minute. Next, gradually add the Mortarcoat aggregate while mixing for an additional 2 minutes. For vertical applications, use Vertical Mortarcoat aggregate. Mixing is complete when no dry clumps of material exist. Pour the material onto the floor and spread out with a 0.4 mm squeegee. Backroll the material with a medium nap roller to remove squeegee lines. The material may appear rough at first but will level out to a smooth finish. For vertical surfaces, use a large steel trowel or knife to pull an initial coat of vertical material onto the wall, then finish smooth with a flat rubber squeegee.

## **Topcoat**

Lightly sand the mortar coat in areas where protrusions exist. Vacuum the area completely. Mix the amine and the resin in a 20-litre mixing container using a heavy-duty, slow-speed drill (400 to 600 rpm) with a Jiffy Mixer for 2 minutes. Pour the material onto the floor and spread out with a 0.4 mm squeegee. Backroll the area with a medium nap roller to remove squeegee lines using long roll strokes to decrease the visibility of roller lines. For vertical surfaces, pour a bead of material along the base of the wall and, using a medium nap roller, roll the material onto the vertical surface. The wet film thickness of the coating is 254 to 305 microns. Check the thickness with a wet film gauge.

#### CURING

The surface of Stonchem 502 will be tack-free in 4 to 6 hours at 21°C. The coated area may be put back in service in 24 hours at 21°C. Ultimate physical characteristics will be achieved in 7 days.

#### **PRECAUTIONS**

- · Avoid contact with Stonchem 500 amine and resin. They may cause skin, respiratory and eye irritation.
- Acetone is recommended for clean up of Stonchem 500 amine and resin material spills. Use this material only in strict
  accordance with the manufacturer's recommended safety procedures. Dispose of waste materials in accordance with
  government regulations.
- The use of NIOSH/MSHA approved respirators using an organic vapor acid gas cartridge is recommended.
- The selection of proper protective clothing and equipment will significantly reduce the risk of injury. Body covering apparel, safety goggles and impermeable nitrile gloves are highly recommended
- In case of contact, flush the area with water for 15 minutes and seek medical attention. Wash skin with soap and water.
- If material is ingested, immediately contact a physician. DO NOT INDUCE VOMITING.
- Use only with adequate ventilation.

## **NOTES**

- Safety Data Sheets for Stonchem 502 are available online at www.stonhard.com or upon request.
- Specific information regarding chemical resistance of Stonchem 502 is available in the Stonchem 500 Series Chemical Resistance Guide.
- A staff of technical service engineers is available to assist with product application or to answer questions related to Stonhard products.
- Requests for technical literature or service can be made through local sales representatives and offices, or corporate offices located worldwide
- The appearance of all floor, wall and lining systems will change over time due to normal wear, abrasion, traffic and cleaning. Generally, high-gloss coatings are subject to a reduction in gloss, while matte-finish coatings can increase in gloss level under normal operating conditions.
- Surface texture of resinous flooring surfaces can change over time as a result of wear and surface contaminants. Surfaces should be cleaned regularly and deep cleaned periodically to ensure no contaminant buildup occurs. Surfaces should be periodically inspected to ensure they are performing as expected and may require traction-enhancing maintenance to ensure they continue to meet expectations for the particular area and conditions of use

IMPORTANT:

Storhard believes the information contained here to be true and accurate as of the date of publication. Stonhard makes no warranty, expressed or implied, based on this literature and assumes no responsibility for consequential or incidental damages in the use of the systems described, including any warranty of merchantability or fitness. Information contained here is for evaluation only. We further reserve the right to modify and change products or literature at any time and without prior notice.

11/24

© 2024 Stonhard www.stonhard.com







+34 933 623 785 +351 227 535 642

+44 1925 649 458







Poland